



How to Upgrade TTP-244 Firmware


1. Install Seagull driver into your computer.




2. Right click on TSC TTP-244 icon then select "Properties...".
3. Click on "Ports" tab. Make sure the communication port is USB interface. **DISABLE the [bidirectional support] feature.**




4. Click on "Tools" tab.



4. Click the [Action] button and select the [Send File To Printer] function.



4. Select the Files of type as “All Files (*.*)” and select the .NEW firmware file then click the button [Open] to start firmware updating process.



Note:

1. Please DO NOT turn off the power while firmware update is in process.
2. When firmware update is in process, the ON-LINE LED blinks all the way until firmware update is completed.
3. When firmware update is completed, the printer will reset automatically and enter ready mode. The LED becomes solid green.